




PDL RESIDUAL CURRENT DEVICE (RCD)

Installation and consumer operating instructions for CAT 691RCD (10mA & 30mA) Vertical Protected Socket Outlet

FEATURES

Your PDL RCD is an electronic sensing device which constantly monitors the balance of current flow between phase and neutral from any permanently connected appliance or socket outlet wired to the unit which has an appliance plugged into it. Should your body contact live parts of this appliance, an imbalance is sensed by the RCD and the supply automatically switches off before current reaches a fatal level. Use of an RCD does not eliminate the need for basic electrical safety precautions.

This product will remain unaffected by loss of power supply.



IMPORTANT NOTES


- Your RCD is designed to protect you against electrical faults to Earth.
- Your RCD is designed for wiring to socket outlets for use with frequently plugged in appliances such as power tools, kitchen appliances and vacuum cleaners or permanently connected appliances, etc.
- Your RCD is designed as a protection device, therefore DO NOT use as an on/off switch.
- It is normal for the front panel of your RCD to be slightly warm during use.
- RCD devices do not protect you against an electrical shock caused by contact with both Phase & Neutral of the electrical circuit.
- Any appliance connected to an RCD unit **MUST** be unplugged or disconnected before any inspection or repair is attempted on the appliance.
- If your RCD does not trip during the test or trips during use, please contact or return to point of purchase for advice.
- Ensure MCB or HRC fuses rated at 20A max are installed in your distribution board to prevent damage to your RCD as it does not provide protection against overload.
- Your RCD includes double pole switching to give added safety.

CLEANING INSTRUCTIONS

Use a clean cloth dampened with water to wipe down unit.

INSTALLATION INSTRUCTIONS

Before wiring, ensure the supply is disconnected at the distribution board and study the connection diagram before terminating wires. **Be careful not to connect the supply line to any terminal other than indicated in the diagram and on the product. Incorrect wiring will cause damage to the RCD.** For your RCD to give protection, the supply must be wired to the LINE IN A/P, and N. If another socket outlet is to be protected down stream of the RCD it must be connected to the terminals marked 'A/P OUT' and 'N OUT'. The common Earth terminal marked 'E' must be used.



TEST INSTRUCTIONS

- Press RESET button and check the indicator has changed from BLACK to RED.
- Press TEST button and check the indicator has changed from RED to BLACK (if your RCD fails the above test, **do not use**).
- Press RESET button to activate your RCD and operate appliance or tool as normal.

SPECIFICATIONS

Mounting centres:	84mm	Average trip time:	30ms
Rating:	230-240V a.c. 50Hz	Operating temp:	-10 to 40°C
Rated current:	20A (RCD protected circuit)	Type tested to:	AS/NZS3190, AS/NZS61008 Clause 9.2.1, Type A
.....	10A (socket outlet)	Residual Current Devices	
Max tripping current (691RCD-30): AC & pulsating DC 30mA			
or Max tripping current (691RCD-10): AC & pulsating DC 10mA			

PRODUCT WARRANTY/12 MONTHS

The PDL Powerguard™ Cat 691RCD has a 12 month warranty from the date of purchase providing the unit is installed according to these instructions, local wiring regulations and Codes of Practice. This warranty is void on any unit which has been tampered with, damaged by accident, improper operation or incorrect installation. This guarantee is in addition to, and does not in any way affect the rights under the Consumer Guarantees Act 1993, if the ACT applies to the supply of this product and you are not acquiring the product for a business use. If the ACT applies and any term is inconsistent with the terms or requirements of the ACT that term shall be invalid without affecting the remaining terms of the warranty.

Note: Under the CGA 1993, Schneider Electric advises that this product does not contain user serviceable components thus spare parts and repair facilities are not available.

In the event of a warranty claim, the product must be returned to the point of purchase or direct to Australia/New Zealand distributors together with the proof of purchase.

NZ Patent No. 239076, No. 242376, No. 280909, No. 280910. Australian Patent AUS665551, AUS694280.



New Zealand Head Office:
PO Box 13 355, New Lynn,
Waikato 0640, New Zealand
Telephone +64-9-829 0490, Fax +64-9-829 0491
www.pdl.co.nz



PDL Industries Australia Pty Ltd
Locked Bag 5500, Baulkham Hills Business Centre
Baulkham Hills NSW 2153 Australia
Freephone 1300 735 266, Pretext 1 300 735 339
Telephone +61 29851 2666, Fax +61 29851 2695
www.pdl.com.au




PDL RESIDUAL CURRENT DEVICE (RCD)

Installation and consumer operating instructions for CAT 691RCD (10mA & 30mA) Vertical Protected Socket Outlet

FEATURES

Your PDL RCD is an electronic sensing device which constantly monitors the balance of current flow between phase and neutral from any permanently connected appliance or socket outlet wired to the unit which has an appliance plugged into it. Should your body contact live parts of this appliance, an imbalance is sensed by the RCD and the supply automatically switches off before current reaches a fatal level. Use of an RCD does not eliminate the need for basic electrical safety precautions.

This product will remain unaffected by loss of power supply.



IMPORTANT NOTES


- Your RCD is designed to protect you against electrical faults to Earth.
- Your RCD is designed for wiring to socket outlets for use with frequently plugged in appliances such as power tools, kitchen appliances and vacuum cleaners or permanently connected appliances, etc.
- Your RCD is designed as a protection device, therefore DO NOT use as an on/off switch.
- It is normal for the front panel of your RCD to be slightly warm during use.
- RCD devices do not protect you against an electrical shock caused by contact with both Phase & Neutral of the electrical circuit.
- Any appliance connected to an RCD unit **MUST** be unplugged or disconnected before any inspection or repair is attempted on the appliance.
- If your RCD does not trip during the test or trips during use, please contact or return to point of purchase for advice.
- Ensure MCB or HRC fuses rated at 20A max are installed in your distribution board to prevent damage to your RCD as it does not provide protection against overload.
- Your RCD includes double pole switching to give added safety.

CLEANING INSTRUCTIONS

Use a clean cloth dampened with water to wipe down unit.

INSTALLATION INSTRUCTIONS

Before wiring, ensure the supply is disconnected at the distribution board and study the connection diagram before terminating wires. **Be careful not to connect the supply line to any terminal other than indicated in the diagram and on the product. Incorrect wiring will cause damage to the RCD.** For your RCD to give protection, the supply must be wired to the LINE IN A/P, and N. If another socket outlet is to be protected down stream of the RCD it must be connected to the terminals marked 'A/P OUT' and 'N OUT'. The common Earth terminal marked 'E' must be used.



TEST INSTRUCTIONS

- 1/ Press RESET button and check the indicator has changed from BLACK to RED.
- 2/ Press TEST button and check the indicator has changed from RED to BLACK (if your RCD fails the above test, **do not use**).
- 3/ Press RESET button to activate your RCD and operate appliance or tool as normal.

SPECIFICATIONS

Mounting centres:84mm
Rating:230-240V a.c. 50Hz
Rated current:20A (RCD protected circuit)
.....10A (socket outlet)
Max tripping current (691RCD-30): AC & pulsating DC 30mA
or Max tripping current (691RCD-10): AC & pulsating DC 10mA

Average trip time:30ms
Operating temp:-10 to 40°C
Type tested to:AS/NZS3190,
AS/NZS61008 Clause 9.2.1, Type A
Residual Current Devices

PRODUCT WARRANTY/12 MONTHS

The PDL Powerguard™ Cat 691RCD has a 12 month warranty from the date of purchase providing the unit is installed according to these instructions, local wiring regulations and Codes of Practice. This warranty is void on any unit which has been tampered with, damaged by accident, improper operation or incorrect installation. This guarantee is in addition to, and does not in any way affect the rights under the Consumer Guarantees Act 1993, if the ACT applies to the supply of this product and you are not acquiring the product for a business use. If the ACT applies and any term is inconsistent with the terms or requirements of the ACT that term shall be invalid without affecting the remaining terms of the warranty.

Note: Under the CGA 1993, Schneider Electric advises that this product does not contain user serviceable components thus spare parts and repair facilities are not available.

In the event of a warranty claim, the product must be returned to the point of purchase or direct to Australia/New Zealand distributors together with the proof of purchase.

NZ Patent No. 239076, No. 242376, No. 280909, No. 280910. Australian Patent AUS665551, AUS694280.



New Zealand Head Office:
PO Box 13 355, New Lynn,
Waikato 0640, New Zealand
Telephone +64-9-829 0490, Fax +64-9-829 0491
www.pdl.co.nz



PDL Industries Australia Pty Ltd
Locked Bag 5500, Baulkham Hills Business Centre
Baulkham Hills NSW 2153 Australia
Freephone 1300 735 266, Pretext 1 300 735 329
Telephone +61 29851 2666, Fax +61 29851 2695
www.pdl.com.au