







# **Meter Box - 230DRAQTPL**









#### **PLEASE NOTE**

- This equipment must be installed and maintained by a qualified electrician in accordance with the appropriate statutory regulations and codes of practice.
- All applicable local, regional and national regulations must be complied with during the installation, use, maintenance and replacement of this device.
- This product should not be installed if, when unpacking it, you observe that it is
- Clipsal cannot be held responsible in the event of noncompliance with the instructions in this document and in the documents to which it refers.
- The service instruction must be observed throughout the life time of this product.


# **A** DANGER

#### HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH


- Turn off all power supplying this product before working on it.
- Use a voltage tester with a suitable rated voltage in order to check that all active conductors aren't energized.
- Carefully inspect the work area to check that no tools or objects could have been left inside the equipment.

Failure to follow these instructions will result in death or serious injury.

## **Package Contents**




**Note:** Follow the orientation for unboxing



Rotate package by 180° with care and remove carton box

### **Parts Identification**




- A Pole filler
- Green label sheet
- Instruction sheet
- **D** Cable lug
- E Screw (M4)
- Cable tie
- **G** Meter isolation link
- H L7 neutral link assembly

GDE59545-03





























**5.** After wiring, push back the meter panel to its original position and tighten the nut.



= Mandatory step to be followed

6. Re-assemble the fuse carrier to the base portion



4. Wiring connection to

neutral link.





2/4

















# **Circuit Protection Device Installation**

















## Cable Protection Slide and Lead Tie-off Point to Help Comply to AS/NZS 3012 for Temporary Installation



1. Pass the leads through cable protection slide at the bottom opening and tie off before plugging into socket outlet

Note: Fill unused space with pole filler




2. Ensure door is closed after installation Note:




= Mandatory step to be followed

Note: To suit temporary and permanent installation, follow local service and installation rules


## **Doorlock Instruction**




1. Knockout the slot from the inside of door



2. Dismount the pre-assembled locking strap



3. Reverse the locking strap in same position and reassemble it with the screws



#### Clipsal by Schneider Electric (Australia) Pty Limited

33-37 Port Wakefield Road Gepps Cross South Australia 5094

**Customer Care Centre** Tel: 1300 369 233

Email: customercare.au@se.com

Fax: 1300 369 288 www.clipsal.com















