

# Actassi

## Quick termination tool

### Tool cutting module preparation

**CAUTION**

Tool safe position

Cat5e & Cat6

(x1)

Cat6A

(x1)

**Ref.VDIB2736CM**

Cat5e & Cat6

Cat5e & Cat6

Cat6A

Cat6A

**CAUTION**

Tool has parts that can pinch/cut. Keep hands and fingers clear.

Use protective cap

1

Put in place the 8 wires cutting module

2

Take off the protective cap

2

Replacement of cutting module

3

Mount of the cutting module

3

Dismount the cutting module

Maxi Ø4 mm

4

Wiring of the 8 wires

Cate5e & 6

Cat6A

5

Locate the wired jack in the jack holder

6

Easy to push and cut the 8 wires with tool closing action

7

Extract the connector from the jack holder

8

Place termination cap on jack and press to make sure it is fully seated

PHA80272

**Schneider Electric Industries SAS**  
35, rue Joseph Monier  
92500 Rueil-Malmaison, France

[www.schneider-electric.com](http://www.schneider-electric.com)



VDIB2736

3 606489 557690