
INSTALLATION INSTRUCTIONS

Model: Ultecon Thermostat UT-M1


Order Code: FAN5856

1 - Cover Removal




CAUTION: Isolate power supply and make safe before wiring the unit to prevent electric shock and equipment damage. Installation should be carried out by a competent person.

2 - Surface Mounting




Screws supplied


3 - Surface Wiring




4 - Wiring to Terminals



5 - Completion



WIRING DIAGRAM



INSTALLATION INSTRUCTIONS

NOTE:

The thermostat requires 230V AC to operate.
In order to correctly adjust the system to room temperature, install the thermostat as far from heat sources, draughts or particularly cold walls (thermal bridges) as possible.

CAUTION:

Before wiring the appliance be sure to turn off the mains power.
The appliance must be wired to the electric mains through a switch capable of disconnecting voltage as per the current New Zealand safety standards. Installation and electrical wiring of this appliance must be made by a qualified technician and in compliance with the current standards.

Distributed by: Simx Limited
Ph: +64 9 259 1660 | Technical Support Ph: +64 9 259 1662
Email: sales@simx.co.nz | www.simx.co.nz

Simx

PUB0217 iss03 02/15

Simx reserves the right to alter technical specifications without prior warning