

Residual Current Devices

Fault Finding Guide

RCD Series

Note: The following appliances may occasionally cause nuisance tripping of the RCD: Water Heaters, Electric Jugs and Kettles, Steam Irons, Dishwashers, Washing Machines, Swimming Pool Equipment, Auto Defrost Refridgerators and Freezers.

Note: If a faulty appliance is discovered, do not use it in an unprotected outlet under any circumstances. The faulty appliance must be repaired by a qualified person before it is used again.

**TEST MONTHLY USING
TEST BUTTON**

Warning: Residual current devices only protect individuals from Active to Earth contact which is the largest cause of electrocution. It will not protect against electric shock resulting from contact with Active and Neutral wires. Electricity can be dangerous - the use of this product cannot be regarded as a substitute for basic electrical safety.


Your Contact Electrician:

Telephone Number:

Installing Electrician

Please Note:

Attach the sticker in prominent position close to RCD.



Gerard Industries Pty Ltd ACN 007 873 529
12 Park Terrace, Bowden, South Australia 5007
Telephone (08) 8269 0511 Facsimile (08) 8340 1724