



AS-SK-IDEAL

ASSIST NOTIFICATION SYSTEM

KIT INCLUDES:


1x AS-CB-1 ASSIST SYSTEM CONTROLLER

Compact and discreet, the ASSIST Controller powers and manages all system components. Featuring status LEDs, bus ports, and a DC input, it supports up to 20 Buttons with Local Indicators. Central placement reduces cabling. Power supplies must remain connected and clearly labelled.




1x AS-ILS-1 ASSIST SYSTEM INDICATOR

Installed in central areas, the System Indicator provides visual and audible alerts for all active notifications. One priority is indicated at a time, the highest taking precedence. Volume is adjustable via rear dial, and secondary units can extend coverage across multiple zones.



2x AS-CP-1 ASSIST BUTTON WITH LOCAL INDICATOR SET

The ASSIST Button raises Red, Yellow, or Green alerts with a simple press and cancels using the smaller secondary button. Each is addressable via rotary switch, supports auxiliary input, and is daisy-chained with bus cabling. Faults show with flashing backlight and tonal warnings. When wired directly to a Button, the Local Indicator lights up in the relevant priority colour upon activation. Ideal for above-door or ceiling placement, it helps responders quickly identify the alert source. Local Indicators remain lit until the corresponding alert is cancelled.



Additional Button and Indicator sets, System Indicators and other accessories are available at your local IDEAL Electrical.

Please visit www.miracle-electronics.com/assist for datasheets, installer guides and FAQ's.